## **AVR Connection Inspection**

Check all the wiring underneath the silver panel on top of machine. Note: The white plugs will be zip tied together. It's not the connection of plugs you're checking it is the wires going into the backside of the plugs. Be sure to pull the wires away from plugs to ensure good connection.

